













- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod


















A

S504-SFW1K/4/11






A	B	C1	C2	C3	D
1	S504-0011	403	1046	16	1/1
2	S504-1008	377	330	15	1/1
3	S504-1009	377	330	15	1/1
4	S504-1010	377	100	15	1/1
5	S504-2007	1050	330	15	1/1
6	S504-2008	1050	330	15	1/1
7	S504-5704	795	100	6,	1/1
8	S504-9001	387	1029,	2,5	1/1
9	S504-7351	795	100	6,	1/1















2








3






4



5



6

**Pflegehinweis!**

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!

